




# TROMBÓN TENOR SINFONIA SERIE T / TENOR TROMBONE SIMPHONY T SERIE

Nº de Aro Rim Nº 	Diámetro interior Inner Rim diameter 	Diámetro exterior Outer Rim diameter 	Copa / CUP T28 Copa pequeña Shallow cup	Copa / CUP T29 Copa media Medium cup	Copa / CUP T30 Copa media Medium cup	Copa / CUP T31 Copa media Medium cup	Copa / CUP T32 Copa profunda Deep cup	Copa / CUP T33 Copa profunda Deep cup	Copa / CUP T34 Copa muy profunda Very deep cup		
			Profundidad de la copa - Depth of the cup *								
			28	29	30	31	32	33	34		
			Granillo m/m - Throat *								
			6,5	6,75	7	7	7,2	7,2	7,5		
5	24,75	39	5T28	5T29	5T30	5T31	5T32	5T33	5T34		
6	25	39	6T28	6T29	6T30	6T31	6T32	6T33	6T34		
8	25,25	39	8T28	8T29	8T30	8T31	8T32	8T33	8T34		
10	25,5	39,5	10T28	10T29	10T30	10T31	10T32	10T33	10T34		
12	25,75	39,5	12T28	12T29	12T30	12T31	12T32	12T33	12T34		
14	26	39,5	14T28	14T29	14T30	14T31	14T32	14T33	14T34		
16	26,5	40	16T28	16T29	16T30	16T31	16T32	16T33	16T34		
20	27	40	20T28	20T29	20T30	20T31	20T32	20T33	20T34		

\* Las medidas dadas para la "Profundidad de copa" y "Granillo" son estándar, pero puedes elegir las tuyas propias.

\* Measurements given in the "Deep of the cup" and "Throat" sections are standard, but you may also choose your own.